## **\$**FLIR



#### INTELLIGENT FIXED-MOUNT SKIN TEMPERATURE SCREENING



The FLIR Elara FR-345-EST is an affordable, fixedmount radiometric camera for accurately measuring skin temperature\* at medium- to high-throughput entry control points. Equipped with on-edge, intelligent face detection, Elara FR-345-EST issues on-screen prompts to individuals when they need to remove glasses, while also guiding them to the correct position for best measurement. The non-contact camera automatically locates and measures the inner canthus (corner of the eye) within one second and provides an instant pass/fail graphic to the individual. Integration with VMS systems further streamlines workflow and decision-making for facilities, while helping security personnel maintain a safe distance from potential health risks. Elara FR-345-EST does not require or save personally identifiable information (PII) for skin temperature screening.

www.flir.com/FR-345-EST



# CONTRACT OF CONTRACT.

#### FAST, AUTOMATED, AND ACCURATE SKIN TEMPERATURE SCREENING

Precise radiometric thermal camera automatically locates and measures the temperature of the inner canthus (corner of the eye)

- Non-contact temperature measurement accurate within ±0.5°C (±0.9°F)
- Fast one-second screen time after individual is correctly positioned, delivering high-throughput screening
- On-camera automatic canthus measurement with visual pass/fail confirmation
- Interactive display guides the user to proper distance and head pose for accurate inner canthus measurement

FLEXIBLE VMS AND ACCESS CONTROL INTEGRATIONS Seamless user experience through major VMS platforms simplifies installation, speeds workflow, and promotes faster decision-making

- Fully integrated setup, and operation available with FLIR United VMS
- Compatible with third party VMS
- Digital I/O support for access control integration
- Portrait and landscape modes available for installation flexibility



INTELLIGENCE AT THE EDGE On-camera algorithms provide rapid, reliable, and

Un-camera algorithms provide rapid, reliable, and actionable screening results

- On-board CNN-based analytics
- Adaptive alarm threshold helps minimize false alarms
- Automatic calibration and self-screen operation provide instant pass/fail feedback
- Automatic face, mask, and eye-wear detection

#### SPECIFICATIONS

Thermal Sensor & Optics	
Array Format (NTSC)	320 × 256
Detector Type	Long-Life, Uncooled VOx Microbolometer
Pixel Pitch	17 μm
Thermal Frame Rate	20 Hz
FOV	45° × 34°
F/#	1.5
Spectral Range	7.5 μm to 13.5 μm
Accuracy [Drift] in Screening Mode	±0.5°C (±0.9°F)
Object Temperature Range	15°C to 45°C (59°F to 113°F); camera provides contrast from -20°C to 120°C (-4°F to 248°F) but will not provide temperature information
Screening Mode Subject Distance	1m ± 0.2m
Visible Light Camera	'
Sensor Type	1920 × 1080
Lens FOV	HFOV = 75° VFOV = 44°
Focal Length	4 mm
F/#	1.6
Sensitivity	0.05 Lux (@ f1.6 AGC ON, 30FPS)
Video	'
Video Compression	Two independent channels of H.264 or M-JPEG for visible One channel of H.264 or M-JPEG for thermal
Streaming Resolution	Thermal: upscaled to VGA (640 × 480) Visible: 1080p (1920 × 1080), 720p (1280 × 720), VGA (640 × 480)
System Integration	'
Ethernet	10/100 Mbps
Network APIs	FLIR SDK FLIR CGI ONVIF Profile S
Digital I/O	Input: one dry alarm contact Output: one photo relay contact 1A max at 24 VAC/30 VDC

Network	
Supported Protocols	IPV4, HTTP, HTTPS, UPnP, DNS, NTP, RTSP, RTP, TCP, UDP, ICMP, IGMP, DHCP, ARP, IEEE 802.1X
General	
Input Voltage	12-30 VDC (±10%) 24 VAC (21-28 VAC) 802.3at (PoE+)
Power Consumption	17 W
Environmental	
IP Rating (Dust & Water Ingress)	IP54
Operating Temperature Range	15°C to 45°C
Storage Temperature Range	-40°C to 70°C
Humidity	0-95% relative
Vandalism	IK10
Compliance & Certifications	
FCC Part 15 (Subpart B, class A) CE Marked RoHS WEEE ONVIF Profile S	
Video Analytics	
Canthus detection and temperature measurement Face detection Mask detection Glasses detection Subject pose and distance detection	
Cyber Security	
IEEE 802.1x TLS Authentication - control & streaming	

TLS Authentication - control & streaming Digest authentication HTTPS encryption Encrypted FW upload Access control via firewall

\*DISCLAIMER: Contagions such as COVID-19, SARS, and other diseases can produce symptoms like elevated skin temperature—a possible sign of infection. While this FLIR camera is not capable of detecting or diagnosing viruses, it represent a simple, preliminary measure for mitigating further contagion and possible rebound, providing the confidence to return to normalcy. FLIR devices are intended for use as an adjunct to clinical procedures in the screening of skin surface temperature. Various environmental and methodological factors can impact thermal imaging; therefore, it should not be relied upon as the sole determinant of a person's body temperature. Use of a medical device will be needed to identify elevated body temperature.

Specifications are subject to change without notice. For the most up-to-date specs, go to www.flir.com

### CORPORATE

HEADQUARTERS FLIR Systems, Inc. 27700 SW Parkway Ave. Wilsonville, OR 97070 USA PH: +1 866.477.3687

#### LATIN AMERICA FLIR Systems Brasil Av. Antonio Bardella, 320 Sorocaba, SP 18085-852 Brasil PH: +55 15 3238 8070

NASHUA FLIR Systems, Inc. 9 Townsend West Nashua, NH 03063 USA PH: +1 866.477.3687

#### CANADA

FLIR Systems, Ltd. 3430 South Service Road, Suite 103 Burlington, ON L7N 3J5 Canada PH: +1 800.613.0507 www.flir.com NASDAQ: FLIR

Equipment described herein is subject to US export regulations and may require a license prior to export. Diversion contrary to US law is prohibited. Imagery for illustration purposes only. ©2020 FLIR Systems, Inc. All rights reserved. 10/12/20

20-1190-SEC-ENT-A4

